

# hydrotec

designed to flow

## INSTRUCTIONS ON HOW TO INSTALL

### A. GENERAL

The drain is designed to work with either 75mm or 50mm diameter waste pipes

### B. CONNECTION OF UNIT TO DRAIN PIPE

1. Cut away on the indicated cut line of the drain unit for connection to 50mm waste pipe or leave intact for connection to 75mm waste pipe.
2. Use acetone or similar cleanser to remove any greasiness from both the 75/50mm spigot as well as from the inside of the relevant fitting that it is being connected to.
3. Before applying PVC glue use 150 grid paper to etch the surface being glued together.
4. Apply PVC glue to both surfaces, namely inside of fitting and outside of spigot.
5. Leave joint undisturbed until fully cured.

### C. INSTALLATION INSTRUCTIONS

The drain unit can be cast into position together with concrete or fitted afterwards into concrete floor. After the drain unit has been fitted into position the entire area around it needs to be waterproofed, with special care being taken to latch a waterproof membrane onto the flange of the drain unit.

It is good practice to re-seal and waterproof around the adjustable head point, after screed has been laid to falls.

Take care to make allowance for thickness of tiles on top screed.

After full installation of the drain, remove the coloured protection cover and fit the stainless steel grid provided into position.

